

HIGH ENERGY ACCELERATOR AREA MONITOR

PLASMA CHAMBER®

PLASMA-ACC SERIES

Model – PLASMA-ACC - Installed

Model – TBM-ACC-X - Portable

FEATURES:

- HIGH MeV BETA, GAMMA, X-RAY, PHOTONS, POSITRONS, PROTONS, MESONS
- WALL MOUNT & BRACKET– **PLASMA-ACC**
- READS UP TO **50 mR/SECOND** (other ranges available)
- DIGITAL READOUT: 6 digit-rate, DOSE RATE
- FLAT RESPONSE - SEALED PLASMA CHAMBER®
- FAST RESPONSE
- ALARMS: AUDIO / VISUAL
- AC OPERATION – **PLASMA-ACC**
- PORTABLE – **TBM-ACC-X**
- BATTERY BACK UP – **TBM-ACC-X (Portable)**
- **IP 64**
- **CE MARK**



**PLASMA-ACC PLASMA CHAMBER
FIXED**



**PLASMA-ACC ~ SINGLE DETECTOR
LOCAL READOUT
WALL MOUNT - FIXED**

AREA MONITOR FOR ACCELERATORS

UNIQUE PLASMA CHAMBER® PROVIDES

MORE ACCURATE RESPONSE

HIGH MeV GAMMA / X-RAYS / PHOTONS / PARTICLES.



**TBM-ACC-X
PORTABLE**

**PLASMA-ACC
FM-9W MULTI-DETECTOR
READOUT
WALL MOUNT - FIXED**

APPLICATION:

Use in Accelerator & Linac facilities for high energy density from High MeV Gammas or X-Rays and from Nano Second Pulsed X-Rays / Photons.



PHOTON PLASMA DETECTOR FOR MEDICAL, INDUSTRIAL & GOVERNMENT

ACCELERATORS WITH X-RAYS OR GAMMAS OVER 2 MeV ENERGY.



**TECHNICAL ASSOCIATES
OVERHOFF TECHNOLOGY**

7051 Eton Ave., Canoga Park, CA 91303
818-883-7043 (Phone) ~ 818-883-6103 (Fax)

sales@usnuclearcorp.com

WWW.TECH-ASSOCIATES.COM

Divisions of



US NUCLEAR CORP

TICKER UCLE

HIGH ENERGY ACCELERATOR AREA MONITOR

PLASMA CHAMBER®

PLASMA-ACC SERIES

Model – PLASMA-ACC - Installed

Model – TBM-ACC-X - Portable

WHY IS THIS CAPABILITY NEEDED?

- Accurately measures high energy particles, X-Rays and events. The 3 MeV and higher X-Rays and Gammas have so much energy that they create dense plasma inside the plasma chamber. The plasma quickly collapses and disappears & the energy turns into minor heat and turbulence.
- The PLASMA-ACC Series accurately collects and displays the amount of energy in the dense plasma before it collapses. Other brands and models do not.

PLASMA-ACC SERIES		
MODEL TYPE	SURVEY METER PORTABLE	AREA MONITOR FIXED
	TBM-ACC-X	PLASMA-ACC
POWER	BATTERY	AC
MULTIDETECTOR SYSTEM	NO	YES
CENTRAL HUB (FM-9W)	N/A	YES
WEIGHT - FM-9W	N/A	3 LBS
WEIGHT	2.9 LBS	1.5 LBS
WALL MOUNT	NO	YES
ALARM	NO	YES
OVER RANGE INDICATOR	YES	YES
LOCAL DISPLAY	YES	OPTIONAL
ULTRA LOW ENERGY WINDOW	STANDARD	AVAILABLE
HANDLE	YES	NO

RESPONSE:

The **PLASMA-ACC Series** are the **ONLY** accelerator plasma chambers® that will detect accelerator produced pulses and radiation. It will accurately measure the integrated Total Dose from high energy radiation and events over a wide range of pulse widths & repetition rates.



TECHNICAL ASSOCIATES
OVERHOFF TECHNOLOGY

7051 Eton Ave., Canoga Park, CA 91303
818-883-7043 (Phone) ~ 818-883-6103 (Fax)

sales@usnuclearcorp.com

WWW.TECH-ASSOCIATES.COM

Divisions of  US NUCLEAR CORP

TICKER UCLE

HIGH ENERGY ACCELERATOR AREA MONITOR

PLASMA CHAMBER®

PLASMA-ACC SERIES

Model – PLASMA-ACC - Installed

Model – TBM-ACC-X - Portable

DESCRIPTION:

The **PLASMA-ACC** consists of a plasma chamber coupled to a Digital display that reads out directly the average mR/h or total mR. and is a fixed mount detector with electronics.

The **TBM-ACC-X** consists of a plasma chamber with read out in a portable hand held instrument.

SPECIFICATIONS:

PULSED X-RAY RESPONSE

MEASURES RADIATION DELIVERED AT 10⁵R/sec FOR THAT 20 NANO SECOND PERIOD

Total Dose:	1 mR to 100 R in a single range (8 digits)
Dose Rate Range:	1 mR/hr to 10,000 mR/hr (6 digits) or 10 mR/h to 100,000 mR/h
Pulse Width Range:	20 nano-seconds to continuous emission
Repetition Rates:	Single pulse to 1000/second
Wide Energy Range:	2 KeV to 10 MeV (Higher energy available for both models)
High Dose Limits:	Per customer specification*
User should inform TA of highest-expected: 10-second, total-dose exposure	
*Note: TA also makes ion chambers that measure up to 10 million R/hr	
Detector:	Sealed Plasma chamber: TBM-ACC-X; PLASMA-ACC

TBM-ACC-X - Portable

Cap:	Removable protective cap
Window:	0.5 mg/cm ² Kapton.
Local Readout:	LCD 8 digits with capacity backlight
Count Lamp:	Green Flashing LED
Over-Range:	Red LED Indicator
Power:	6 AA Batteries
Dimensions:	5-1/2" x 3-1/2" x 8" including handle.
Weight:	2.9 lbs. complete with batteries.



**TECHNICAL ASSOCIATES
OVERHOFF TECHNOLOGY**

7051 Eton Ave., Canoga Park, CA 91303
818-883-7043 (Phone) ~ 818-883-6103 (Fax)

sales@usnuclearcorp.com

WWW.TECH-ASSOCIATES.COM

Divisions of  US NUCLEAR CORP
TICKER UCLE

HIGH ENERGY ACCELERATOR AREA MONITOR

PLASMA CHAMBER®

PLASMA-ACC SERIES

Model – PLASMA-ACC - Installed

Model – TBM-ACC-X - Portable

PLASMA-ACC – Installed / Wall Mounted

PLASMA-ACC - Read Out Electronics: FM-9W – Multi-detector Hub System

Engineering Units:	User can input correct conversion factor and change to any units.
Controls: Front Panel:	On-Off, Alarm-mute, Rate, Integrate, Reset, Digital
Recessed or Internal:	Discriminator level, high voltage. Other adjustable settings.
Input Sensitivity:	Adjustable from less than 1 millivolt to 100 millivolt Anti-saturation and Dead-time Corrections are available.
Alarm Audio & Visual:	2000 Hz audio tone with Audio “mute” switch + RED LIGHT High current relay. 0-100% of full scale.
Alarm Set Point:	User settable to any point on detector range.
Serial Output:	Two way USB standard, Ethernet optional.
Power:	105-125 volts, 50-60 Hz (220 V optional)
Construction:	Gasketed aluminum case.
Cables:	User Specified

OPTIONAL:

Read Out:	Local – Single Detector
Power:	AC 110/220

ELECTRONICS - FM-9W - DIMENSIONS & WEIGHT:

13.5" W X 11" H X 3.6" D (25 cm x 18 cm x 10cm), excluding probe holder, feet, and knobs.

3 pounds (1.4 kg) including batteries and hardware, excluding probe.

WEIGHT – PLASMA DETECTOR

1.5 LBS

Options:

Other Rates or Integrated Ranges

Other Readout Units such as Si units: Sv and Sv/h.



TECHNICAL ASSOCIATES
OVERHOFF TECHNOLOGY

7051 Eton Ave., Canoga Park, CA 91303
818-883-7043 (Phone) ~ 818-883-6103 (Fax)

sales@usnuclearcorp.com

WWW.TECH-ASSOCIATES.COM

Divisions of  US NUCLEAR CORP
TICKER UCLE